

HYDRAVENT

BEST PRACTICES

When installing Hydravent for under a liner, consider the following practices:

- Is the subgrade properly graded and free of large rocks and debris?
- When installing Hydravent:
 - Insert a pole in the middle of the Hydravent roll.
 - Have 2 people on either side of the roll and have the Hydravent unroll off the top of the roll. This will prevent having to flip the unrolled Hydravent.
 - Note: there is a large yellow label on the end of the roll that states “this side up” in both English and Spanish.
- Sand Bags:
 - In order to keep Hydravent in place when pulling the liner over the system, use sand bags to hold the system in place. It is not recommended to use fabric pins or staples as they might puncture the liner.
- Splices:
 - Hydravent comes in 150 ft long rolls. If you need to add more Hydravent to the length of the installed piece, splices are recommended to join the two ends. Secure the splice in place with mastic tape or Gorilla tape.
- If you need to run a lateral at an angle, simply cut the Hydravent with a razor knife to the desired angle and secure with mastic tape.
- Keep all wheeled traffic off the Hydravent once installed.
- UV Protective Wrap
 - It is not recommended to unwrap the Hydravent from its protective black plastic until ready to install. UV rays will deteriorate the geotextile on the Hydravent.
 - Any unused Hydravent should be re-wrapped or stored out of the sun light.